


Read this instruction carefully.

See hardware and furniture part list for guidance. Be sure all parts are complete, before you assemble. Place all wooden furniture part on a clean and flat soft surface to prevent from being scratched.

- CAUTION:**
1. Do not fully-tighten the JCBC bolt until all is ready assemble.
 2. Do not over-tighten the JCBC bolt to avoid causing damages to the thread.



PART LIST		
ITEM	DESCRIPTION	QTY
1	CHAIR BACK	1 PC
2	FRONT LEGS (L&R)	2 PCS
3	CUSHION SEAT	1 PC
4	COVER UNDER THE SEAT	1 PC

ITEM	DESCRIPTION	PICT.	QTY
A	JCBC SCREW M8*60MM		1 PC
B	JCBC SCREW M8*75MM		8 PCS
C	WASHER		9 PCS
D	ALLEN KEY		1 PC
E	SPRING WASHER		9 PCS

