


DC1602(B)

Emitter Specification

Version NO. : B/01

T Type specification



DC1602(B)
15 - channel LCD emitter


DC1602(B) Back side

T Technical support

Technical specification	Function instruction
<ul style="list-style-type: none"> Input voltage: 3V(CR2450) Transmitting frequency: 433MHz Transmitting power: 10 milliwatt Operating temperature: -10°C—50°C Transmission distance: 200 meters open office, 35 meters on two walls 	<p>DC1602(B) is 15-channel LCD emitter. One number of LCD screen means one control channel. Press "channel choose" button P1- (number descending) or P1+ (number increasing) to change the channel. On the analogy of this, loose finger when the indicator light move to suitable channel that you select effective channel. If LCD screen number show "0" that means all channels if effective (group control state).</p> <p>CAUTION RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS</p> <p>Notice: transmitter do not exposed to moisture and strike, so as not to affect life. When you use transmitter, if found emission distance obviously short or less sensitive, please change another same new battery. Please have batteries for recycling.</p>


A Additional function

Matchable R tubular motor setting up ⚠ Delete all the datas of the motor and the new emitter has been programmed.




A Additional function

Matchable DC1680 setting up ⚠ During the settings, the time between two operation must be shorter than 6s, otherwise it will quit the setting



A Additional function

Matchable DC136 setting up ⚠ During the settings, the time between two operation must be shorter than 10s, otherwise it will quit the setting



A Additional function

The valid channels selection ⚠ In the setting state, press the up or down button you can quit quickly, if you want to change the valid channels, reset it.

